


# Pump InverPilot

InverPilot 1,1 kW	220-240 V 50/60 Hz	1,1 kW	14992002
InverPilot 1,5 kW	220-240 V 50/60 Hz	1,5 kW	14992003



## Reservdelar/Spare parts

	Benämning	Description	Art.nr./ Art. No.
<b>A</b>	Unionsmutter Inverpilot	Union nut InverPilot	635327
<b>B</b>	Unionskoppling 63mm-DB23/28	Union 63 mm-DB23/28	635326
<b>C</b>	O-ring för unionsmutter InverPilot	Union nut o-ring InverPilot	635328
<b>D</b>	Mutter för lock InverPilot	Nut for lid InverPilot	635332
<b>E</b>	Transparent lock InverPilot	Transparent InverPilot	635331
<b>F</b>	Transparent lock O-Ring InverPilot (132x5,3)	Transparent lid o-ring InverPilot	635330
<b>G</b>	Silkorg InverPilot	Strainer basket InverPilot	635329
<b>H</b>	O-ring diffuser InverPilot 1,1kw (73x3,55) + invereasy	Diffuser o-ring 1,1kw (73x3,55) + Invereasy	635342
<b>H</b>	O-ring diffuser InverPilot 1,5 kw (71x4,5)	Diffuser o-ring InverPilot 1,5 kw (71x4,5)	635343
<b>I</b>	Diffuser	Diffuser	635339
<b>I</b>	Diffuser 1,1 kw	Diffuser 1,1 kw	635340
<b>I</b>	Diffuser 1,5 kw	Diffuser 1,5 kw	635341
<b>J</b>	Ej lagerförd reservdel	Non-stock spare part	N/A
<b>K</b>	Ej lagerförd reservdel	Non-stock spare part	N/A
<b>L</b>	Impeller InverPilot	Impeller InverPilot	635335
<b>L</b>	Impeller InverPilot 1,1 Kw + Invereasy	Impeller InverPilot 1,1 Kw + Invereasy	635336
<b>L</b>	Impeller InverPilot 1,5 Kw	Impeller InverPilot 1,5 Kw	635337
<b>M</b>	O-ring tätplatta InverPilot (186,7x191,7)	Seal plate o-ring InverPilot (186,7x191,7)	635344
<b>N</b>	Tätplatta InverPilot	Seal plate InverPilot	635345
<b>O</b>	Ej lagerförd reservdel	Non-stock spare part	N/A
<b>P</b>	Ej lagerförd reservdel	Non-stock spare part	N/A
<b>Q</b>	Inverterstyrning InverPilot 1,1 kw	Inverter controller InverPilot 1,1 kw	635346
<b>Q</b>	Inverterstyrning InverPilot 1,5 kw	Inverter controller InverPilot 1,5 kw	635347
<b>R</b>	Flätkåpa InverPilot	Fan cover InverPilot	635348
<b>S</b>	Motor InverPilot 1,1 kw	Motor InverPilot 1,1 kw	635352
<b>S</b>	Motor InverPilot 1,5 kw	Motor InverPilot 1,5 kw	635353
<b>T</b>	Ej lagerförd reservdel	Non-stock spare part	N/A
<b>U</b>	Axeltätning InverPilot	Mechanical seal InverPilot	635349
<b>V</b>	O-ring Impeller InverPilot (17x2,65)	Impeller o-ring InverPilot (17x2,65)	635338
<b>W</b>	Ej lagerförd reservdel	Non-stock spare part	N/A
<b>X</b>	Dräneringsplugg InverPilot	Drain plug InverPilot	635333
<b>Y</b>	O-Ring för dräneringspump InverPilot (10x3) + Invereasy	Drain plug o-ring InverPilot (10x3) + Invereasy	635334
<b>Z</b>	Pumphus InverPilot	Pump housing InverPilot	635357
<b>AA</b>	Reducer (63x50) InverPilot	Reducer (63x50) InverPilot	635350
<b>AA</b>	Reducer (60,3x48,3) InverPilot	Reducer (60,3x48,3) InverPilot	635351

SVENSKA

SVENSKA

ENGLISH

ENGLISH

## Reservdelar/Spare parts

-	Styrhölje glas till InverPilot	Controller housing with temper glass -DB23/28	635354
-	Displaykort InverPilot 1,1 kw	Display board-DB23/	635355
-	Displaykort InverPilot 1,5 kw	Display board-DB28	635356

SVENSKA

SVENSKA

ENGLISH

ENGLISH